

AUTEL®



Norwegian OBFCM Upload Process

- 01** Conditions Required before use
- 02** Overview of OBFCM upload procedure

Conditions Required before use


1. Your workshop should be registered with at least one of the following three IT suppliers:

- Bus.no
- Inputdada.no
- Pkkhuset.no




2. An Autel tablet

Overview of OBFCM upload procedure:





Configure the IT supplier and log in

1. Open the OBFCM button in the setting page





Configure the IT supplier and log in

2. Select your workshop's IT supplier, enter the username (company ID registered in the selected supplier) and password, then confirm





EOBD—“AutoScan”

3. Open the EOBD function and select AutoScan




Vehicle Information - OBFCM

4. Select the OBFCM function in the Vehicle Information section.



A grey rectangular button with rounded corners and a thin black border, containing the word "Upload" in white text.


5. Click "Upload" after reading the relevant data



You will receive a confirmation message once the upload is successful

Problem shooting:

- **If the upload fails, there could be two possible reasons: one is that the vehicle has already been uploaded within a short period, and there's no need to upload it again. The other is that the vehicle is too old and does not support uploading.**





Problem shooting:

- If the issue persists, please upload the following two logs:
 1. One log should be uploaded using the button in the red box
 2. The other log should be uploaded using the Log Collection in MaxiTools.

Then please contact Support.eu@autel.com and provide your **device serial number** and a **description** of the issue.

Our team is ready to offer you a solution at any time.



THANK YOU

